



Note: Strongbacks should not touch or bear onto flanking walls to prevent load and sound transfer